


Note: Refer to the C1000 Owner's Manual page 4 for additional connection information.

Connection Legend:

- Data Cable* - — Controller to Preamp Cable - —
- Sensor/Keypad Cable - — Ground Wire - —
- Power Control Cable* - — AC Power Cords - —
- Audio Signal Cable - — Loudspeaker Cable - —

* 2 conductor shielded with 1/8 inch stereo mini phone plug on each end.





Note: Refer to the C1000 Owner's Manual page 4 for additional connection information.

Connection Legend:

- Data Cable* - — Controller to Preamplifier Cable - —
- Sensor/Keypad Cable - — Ground Wire - —
- Power Control Cable* - — AC Power Cords - —
- Audio Signal Cable - — Loudspeaker Cable - —

* 2 conductor shielded with 1/8 inch stereo mini phone plug on each end.

McIntosh Left Channel Power Amplifier



Connect to AC Outlet

McIntosh Right Channel Power Amplifier

