





Note: Refer to the C1000 Owner's Manual page 4 for additional connection information.

**Connection Legend:**

- Data Cable\* - — Controller to Preamplifier Cable - —
- Sensor/Keypad Cable - — Ground Wire - —
- Power Control Cable\* - — AC Power Cords - —
- Audio Signal Cable - — Loudspeaker Cable - —

\* 2 conductor shielded with 1/8 inch stereo mini phone plug on each end.




Note: Refer to the C1000 Owner's Manual page 4 for additional connection information.



**Connection Legend:**

- Data Cable\* - — Controller to Preamplifier Cable - —
  - Sensor/Keypad Cable - — Ground Wire - —
  - Power Control Cable\* - — AC Power Cords - —
  - Audio Signal Cable - — Loudspeaker Cable - —
- \* 2 conductor shielded with 1/8 inch stereo mini phone plug on each end.

McIntosh Left Channel Power Amplifier



McIntosh Right Channel Power Amplifier



Connect to AC Outlet

