





Note: Refer to the MA8000 Owner's Manual pages 9 and 10 for additional connection Power Amplifier - Secondary Room information. Connection Legend: Data Cable*-Digital Signal Cable -RS232 Cable -Sensor/Keypad Cable -Ground Wire -Power Control Cable* -Audio Signal Cable -AC Power Cords -Video Signal Cable -Loudspeaker Cable -Right Loudspeaker - Secondary Room Left Loudspeaker - Secondary Room RF Signal Cable -* 2 conductor shielded with 1/8 inch stereo mini phone plug on each end. GAUTION PIECO ELECTRIC SHOCK DO NOT OPEN Connect to POWER CONTROL IN OUT POWER CONTROL AC Outlet *** (**P) **(4**) R OUTPUT 4 4 LOUTPUT Left Loudspeaker Right Loudspeaker — DIGITAL AUDIO INPUTS— POWER CTRL MAIN O O DIG 2 DIG 4 (a) TRIG 2 Connect to AC Outlet (€