

Note: Refer to the C1100 Owner's Manual page 11 for additional connection information. Turntable with Moving Coil Cartridge Connection Legend: Data Cable*-Digital Signal Cable -RS232 Cable -Sensor/Keypad Cable -Power Control Cable* -Ground Wire -Audio Signal Cable -AC Power Cords -Video Signal Cable -Loudspeaker Cable -RF Signal Cable -* 2 conductor shielded with 3.5mm stereo mini phone plug on each end. Media Bridge UNBALANCED BALANCEI 0 IR Sensor DC N USBS 197 eSATA NET USB 197 USB 19 ጆ (€ 4 (4) **O** 0 0 0 \odot 0 C€ 0 0 0 AM/FM Tuner RIGHT OUTPUT LEFT OUTPUT MtIntosh C1100 CONTROLLER RAA2 AM ANT C1100 TUBE PREAMPLIFIER LEFT INPUT TO C1100 TUBE PREAMPLIFIER RIGHT INPUT (::::) To C1100T To C1100T UNBAL Right Input Left Input (E 🗵 SERIAL NUMBER SACD/CD Player **(‡)** Digital Audio Player R 🔘 DIGITAL UNBAL DIGITAL

O COAX

OPTICAL

DO PR

OPTICAL SERIAL NUMBER UNBAL L UNBALANCED DC IN 5V

Use Only The Power Adapter Proving DIGITAL AUDIO OUTPUTS COAXIAL USB CE SERIAL NUMBER



Note: Refer to the C1100 Owner's Manual page 11 for additional connection information. Turntable with Moving Coil Cartridge Connection Legend: Data Cable*-Digital Signal Cable -Sensor/Keypad Cable -RS232 Cable -Power Control Cable* -Ground Wire -Audio Signal Cable -AC Power Cords -Video Signal Cable -Loudspeaker Cable -RF Signal Cable -* 2 conductor shielded with 3.5mm stereo mini phone plug on each end. Media Bridge UNBALANCED BALANCED DATA IN SPDIF R ጃ (€ **(4**) AM/FM Tuner RAA2 AM ANT ANT LEFT UNBALANCED DATA IN RIGHT INPUT LEFT INPUT C1100 TUBE PREAMPLIFIER GND (:...) 0 TO C1100 CONTROLLER RIGHT OUTPUT TO C1100 CONTROLLER LEFT OUTPUT From C1100C From C1100C SERIAL CE Left Output Right Output SACD/CD Player Digital Audio Player . 🔘 IR DATA CONTROL
IN IN OUT IN
OO OO OO DIGITAL UNBAL DIGITAL UNBAL

O O L O O L

O R

OPTICAL

OPTICAL

OPTICAL R 🔘 R 🔘 LINBAL ANCED III Intosh MCD550 COAXIAL USB CE SERIAL NUMBER