


Note: Refer to the C2700 Owner's Manual page 7&8 for additional connection information.




Connection Legend:

- Data Cable* - — Digital Signal Cable -
 - Sensor/Keypad Cable - — RS232 Cable -
 - Power Control Cable* - — Ground Wire -
 - Audio Signal Cable - — AC Power Cords -
 - Video Signal Cable - — Loudspeaker Cable -
 - RF Signal Cable -
- * 2 conductor shielded with 1/8 inch stereo mini phone plug on each end.

Power Amplifier (Right Channel) - Main Room
(Partial View)



Power Amplifier (Left-Channel) - Main Room
(Partial View)



Connect to AC Outlet

C2700 Rear Panel Connections

