




C500 Controller / C500P or C500T Preamplifier Input and Control Connection Diagram

Note: Refer to the C500 Owner's Manual page 12 for additional connection information.

Connection Legend:

- Data Cable* - — Digital Signal Cable - —
 - Sensor/Keypad Cable - — RS232 Cable - —
 - Power Control Cable* - — Ground Wire - —
 - Audio Signal Cable - — AC Power Cords - —
 - Video Signal Cable - — Loudspeaker Cable - —
 - RF Signal Cable - —
- * 2 conductor shielded with 1/8 inch stereo mini phone plug on each end.





C500 Controller / C500P or C500T Preamplifier Output and Control Connection Diagram

Note: Refer to the C500 Owner's Manual page 12 for additional connection information.

Connection Legend:

- Data Cable* - — Digital Signal Cable - —
- Sensor/Keypad Cable - — RS232 Cable - —
- Power Control Cable* - — Ground Wire - —
- Audio Signal Cable - — AC Power Cords - —
- Video Signal Cable - — Loudspeaker Cable - —
- RF Signal Cable - —

* 2 conductor shielded with 1/8 inch stereo mini phone plug on each end.

