


STEP 1

REMOVE AC/DC POWER SUPPLY

REMOVE AC CORD & Wi-Fi ANTENNAS

REMOVE REMOTE CONTROL


REMOVE UNIT FROM CARTON



STEP 2

REMOVE PROTECTIVE COVER

COVER




STEP 3

INSTALL BATTERIES

REMOVE SCREW

RE-INSERT SCREW




STEP 4

CONNECT THE ANTENNAS

WLAN ANTENNA CONNECTORS

SUPPLIED Wi-Fi ANTENNAS


Refer to pages 10 and 11 in the MB50 Owner's Manual for additional information.



STEP 5

CONNECT THE SUPPLIED AC CORD

CONNECT THE SUPPLIED AC/DC POWER SUPPLY TO THE MB50 CONNECTOR



STEP 6

THE MB50 IS COMPATIBLE WITH BOTH APPLE POWERED AND ANDROID POWERED MOBILE DEVICES. THERE ARE OPERATIONAL DIFFERENCES BETWEEN BOTH TYPES OF MOBILE DEVICES.

WHEN USING AN APPLE POWERED MOBILE DEVICE, PROCEED TO STEP 7 ON SHEET 2 OF THIS QUICK START GUIDE.

WHEN USING AN ANDROID POWERED MOBILE DEVICE, PROCEED TO STEP 11 ON SHEET 5 OF THIS QUICK START GUIDE.

STEP 7

DOWNLOAD AND INSTALL THE PLAY-FI APP TO YOUR APPLE POWERED MOBILE DEVICE

MOBILE DEVICE

The Play-Fi App for Music Streaming and Remote Operation of the MB50 is available at the Web Site for download free of charge:

For Apple Powered Mobile Devices:
<https://itunes.apple.com/us/app/play-fi/id779245456?mt=8>

PLAY-FI APP



NOTE:
 The graphic illustration of this Apple Powered Mobile Device may vary slightly from your Apple Mobile Device.

STEP 8

ESTABLISH CONNECTION WITH A WIRELESS ROUTER

NOTE: If your Apple Powered Mobile Device is currently Wi-Fi Connected to your Wireless Router, proceed to STEP 9.


SELECT SETTINGS



SELECT Wi-Fi SETTINGS



SELECT YOUR ROUTER



NOTES:

- ¹ Refer to the MB50 Owner's Manual, page 5, note 3 for additional information.
- ² The term "Your Network" is used to refer to the name of the wired Network (with Wireless Router) connected to the MB50 or just a Network Wireless Router used with the MB50.
- ³ It is advisable, during the initial communications setup, to physically locate the MB50 and the Wireless Router in close proximity to one another.
- ⁴ If there is difficulty in establishing communications between the network Router, MB50 and/or the Mobile Device, temporarily switch Off other Wi-Fi devices connected to the same Router.

MB50 Quick Start Guide Sheet 3 (for Apple Powered Devices)

STEP 9


ESTABLISH COMMUNICATIONS WITH THE MB50

1st - POWER ON THE MB50



2nd - GREEN LED INDICATES WHEN THE MB50 IS IN THE SETUP MODE, FOR ESTABLISHING WIRELESS OR WIRED NETWORK CONNECTIONS

3rd - SELECT "Play-Fi APP"



4th - SELECT "Set-up New Device"
NOTE: Proceed with "Set-up new Device" after the "WI-FI/NET" LED indicator changes from flashing rapidly to slowly pulsing On/Off.



5th - SELECT "Settings"



6th - SELECT "Wi-Fi"



7th - LOCATES Play-Fi Device (MB50)



8th - Setting Up communications with MB50



9th - Communications established with MB50

Proceed to STEP 10 on next page


MB50 Quick Start Guide Sheet 4 (for Apple Powered Devices)

STEP 10


Play-Fi Settings



1st - SELECT "Play-Fi APP"



2nd - SELECT "Your Network"




3rd - Enter your Network Password if required


4th - SELECT "Set-up"




Play-Fi Connecting to Your Router



5th - SELECT the name of the room where the MB50 is located



6th - SELECT "Location Name"
NOTE: The "WI-FI/NET" LED indicator will change from slowly pulsing On/Off to On all the time.



7th - SELECT "Music" to start playback of desired music

REFER TO THE MB50 OWNER'S MANUAL PAGES 10 and 11 FOR CONNECTION OF ADDITIONAL EQUIPMENT TO THE MB50 FOR LISTENING

IF HEADPHONES ARE THE PRIMARY LISTENING METHOD, PLEASE REFER TO PAGE 16 "HOW TO OPERATE" SECTION OF THE MB50 OWNER'S MANUAL

MB50 Quick Start Guide Sheet 5 (for Android Powered Devices)

STEP 11

DOWNLOAD AND INSTALL THE PLAY-FI APP TO YOUR ANDROID POWERED MOBILE DEVICE


MOBILE DEVICE

The Play-Fi App for Music Streaming and Remote Operation of the MB50 is available at the Web Site for download free of charge:

For Android Powered Mobile Devices:
<https://play.google.com/store/apps/details?id=com.phorus.playfi&hl>

PLAY-FI APP

NOTE:
The graphic illustration of this Android Powered Mobile Device may vary slightly from your Android Mobile Device.




STEP 12


ESTABLISH CONNECTION WITH A WIRELESS ROUTER

NOTE: If your Android Powered Mobile Device is currently Wi-Fi Connected to your Wireless Router, proceed to STEP 13.



SELECT SETTINGS



SELECT Wi-Fi SETTINGS




SELECT YOUR ROUTER



WIRED NETWORK WITH WIRELESS Wi-Fi ROUTER

OR

WIRELESS NETWORK Wi-Fi ROUTER



NOTES:

- ¹ Refer to the MB50 Owner's Manual, page 5, note 3 for additional information.
- ² The term "Your Network" is used to refer to the name of the wired Network (with Wireless Router) connected to the MB50 or just a Network Wireless Router used with the MB50.
- ³ It is advisable, during the initial communications setup, to physically locate the MB50 and the Wireless Router in close proximity to one another.
- ⁴ If there is difficulty in establishing communications between the network Router, MB50 and/or the Mobile Device, temporarily switch Off other Wi-Fi devices connected to the same Router.

MB50 Quick Start Guide Sheet 6 (for Android Powered Devices)


STEP 13

ESTABLISH COMMUNICATIONS WITH THE MB50


1st - POWER ON THE MB50



2nd - GREEN LED INDICATES WHEN THE MB50 IS IN THE SETUP MODE, FOR ESTABLISHING WIRELESS OR WIRED NETWORK CONNECTIONS





3rd - SELECT "Play-Fi APP"





4th - SELECT "Set-up New Device"

NOTE: Proceed with "Set-up new Device" after the "WI-FI/NET" LED indicator changes from flashing rapidly to slowly pulsing On/Off.




5th - ENTER "Network (Router) Password"


6th - SELECT "Next"



7th - SELECT the name of the room where the MB50 is located



8th - SELECT "Location Name"
NOTE: The "WI-FI/NET" LED indicator will change from slowly pulsing On/Off to On all the time.



9th - SELECT "Music" to start playback of desired music

REFER TO THE MB50 OWNER'S MANUAL PAGES 10 and 11 FOR CONNECTION OF ADDITIONAL EQUIPMENT TO THE MB50 FOR LISTENING

IF HEADPHONES ARE THE PRIMARY LISTENING METHOD, PLEASE REFER TO PAGE 16 "HOW TO OPERATE" SECTION OF THE MB50 OWNER'S MANUAL