





*Note: When there are grayed out menu items appearing, other Setup Mode Options need to be activated first in order to make changes.*



*Note: When there are grayed out menu items appearing, other Setup Mode Options need to be activated first in order to make changes.*



*Note: When there are grayed out menu items appearing, other Setup Mode Options need to be activated first in order to make changes.*



**Video** McIntosh

- Picture Adjust
- HDMI Setup
- Output Settings
- Analog Video Out
- On Screen Display
- TV Format

Adjusts the video quality for each video input source

**Video/Analog Video Out** McIntosh

ZONE MAIN ZONE

Assigns the "monitor" component and composite video outputs to the main zone or zone 3

**Video/On Screen Display** McIntosh

Volume Bottom

Info On

Now Playing Always On

Selects where to display the on-screen volume indicator

**Video/TV Format** McIntosh

Format NTSC

Select the video output signal format to match the monitor

**Video/HDMI Setup** McIntosh

Auto Lip Sync	On
HDMI Audio Out	AVP
Video Output	Auto(Dual)
Vertical Stretch	Off
HDMI Pass Through	On
HDMI Control	Off
-Pass Through Source	CBL/SAT
-TV Audio Switching	On
-Power Off Control	All

Adjusts the timing of the audio and video signals

*Note: When there are grayed out menu items appearing, other Setup Mode Options need to be activated first in order to make changes.*

**Video/Output Settings** McIntosh

Video Mode	Auto
Video Conversion	On
i/p Scaler	Analog
-Resolution (analog)	Auto
-Resolution (HDMI)	Auto
-Progressive Mode	Auto
-Aspect Ratio	16:9

Selects the video processing mode

*Note: When there are grayed out menu items appearing, other Setup Mode Options need to be activated first in order to make changes.*

**Inputs** McIntosh

**Input Assign**

Source Rename

Hide Sources

Source Level

Input Select

Assigns AVP inputs to source devices by name

**Inputs/Input Assign** McIntosh

Set Defaults

	HDMI	DIGITAL	ANALOG	COMP	VIDEO
CBL/SAT	1	COAX1	1	1	1
DVD	2	COAX2	2	2	2
Blu-ray	3	-	3	3	3
Game	4	-	4	-	4
Media Player	5	-	6	-	-
TV Audio	-	OPT1	-	-	-
AUX	6	-	-	-	-
CD	7	OPT2	5	-	-

Changes HDMI input assignments

**Inputs/Hide Sources** [1/2] McIntosh

CBL/SAT Show

DVD Show

Blu-ray MAIN ZONE

Game Show

Media Player Show

TV Audio Show

AUX Show

CD Show

Phono Show

Favorites Show

Internet Radio Show

Selects the input you want to Show or Hide

**Inputs/Source Rename** McIntosh

Set Defaults

CBL/SAT	CBL/SAT
DVD	DVD
Blu-ray	Blu-ray
Game	Game
Media Player	Media Player
TV Audio	TV Audio
AUX	AUX
CD	CD
Phono	Phono
Tuner	Tuner

Changes the display name for this source

**Inputs/Input Select** McIntosh

Input Mode Auto

Decode Mode Auto

Selects which connection to use for the current input

**Inputs/Source Level** McIntosh

Analog Inputs 0 dB

Digital Inputs 0 dB

Adjusts the analog input level

**Inputs/Source Rename** McIntosh

CD CD

Clear Insert Delete ← →

A B C D E F G H I J K L M

N O P Q R S T U V W X Y Z

0 1 2 3 4 5 6 7 8 9 ! " #

\$ % & ' ( ) \* + , ; < = >

a / A Space Cancel O K

Changes the display name for this source

**Inputs/Source Level** McIntosh

Analog Inputs +6 dB

Digital Inputs 0 dB

Adjusts the analog input level

**Speakers**  
Audyssey Setup  
Manual Setup

Automatically optimize speaker settings and correct room acoustics

**Audyssey Setup**

Your AV preamp can automatically measure the acoustics of your room then optimize your speakers using the included microphone and microphone stand. Set the following items if necessary.

Amp Assign  
Channel Select

Start

Note: Before starting Audyssey, it is very important to enter the Loudspeaker Room Configuration and Amplifier Assignment first. Refer to pages 28 thru 31 in the MX122 Owner's Manual for additional information.

**Channel Select**

Subwoofer Measure (1 spkr)  
Surround Back Measure (2 spkrs)

Allows you to skip measurement of unused channels to reduce speaker calibration time

**Amp Assign**

Assign Mode 11.1ch

Floor  
-Layout 5ch & SB & FW  
Height  
-Height Sp 2ch  
-Dolby Sp None  
-Layout Front Height

View Terminal Config.

Support Format :Dolby Atmos, DTS:X, Audyssey DSX, Auro-3D  
Selects how to use the pre amplifiers

**Amp Assign**

Assign Mode 11.1ch

Floor  
-Layout 5ch & SB & FW  
Height  
-Height Sp 2ch  
-Dolby Sp None  
-Layout Front Height

View Terminal Config.

Support Format :Dolby Atmos, DTS:X, Audyssey DSX, Auro-3D  
Select the floor speaker location

**Amp Assign**

Assign Mode 11.1ch

Floor  
-Layout 5ch & SB & FW  
Height  
-Height Sp 2ch  
-Dolby Sp None  
-Layout Front Height

View Terminal Config.

Support Format :Dolby Atmos, DTS:X, Audyssey DSX, Auro-3D  
Select the number of height speakers and ceiling speakers to be used

**Amp Assign**

Assign Mode 11.1ch

Floor  
-Layout 5ch & SB & FW  
Height  
-Height Sp 2ch  
-Dolby Sp None  
-Layout Front Height

View Terminal Config.

Support Format :Dolby Atmos, DTS:X, Audyssey DSX, Auro-3D  
Select the number of Dolby Atmos Enabled speakers to be used

**Amp Assign**

Assign Mode 11.1ch

Floor  
-Layout 5ch & SB & FW  
Height  
-Height Sp 2ch  
-Dolby Sp None  
-Layout Front Height

View Terminal Config.

Support Format :Dolby Atmos, DTS:X, Audyssey DSX, Auro-3D  
Select the height, ceiling, or Dolby Atmos Enabled speaker location



**Amp Assign**

Assign Mode 11.1ch



RCA  
XLR

FR FL C SW1 SW2 SR SL SBR SBL FHR FHL WL WR





Back



To Amplifier Assignment and Loudspeaker Room Configuration continues on separate page **Mc** MX122 MENU -7





Note: When there are grayed out menu items appearing, other Setup Mode Options need to be activated first in order to make changes.




From Speakers/Amp Assign on separate page **Mc** MX122 MENU -7

From Speaker/Manual Setup on separate page **Mc** MX122 MENU - 6




To Speakers/Speaker Config. continues on separate page **Mc** MX122 MENU - 6



*Note: When there are grayed out menu items appearing, other Setup Mode Options need to be activated first in order to make changes.*





Note: When there are grayed out menu items appearing, other Setup Mode Options need to be activated first in order to make changes.